

## HEATMISER PROGRAMMING QUICK GUIDE

**STEP BY STEP INSTRUCTIONS TO ALTER ANY OF THE SECTIONS BELOW**

<p><b>PROGRAMMING SWITCHING TIMES</b></p> <ul style="list-style-type: none"> <li>• Press PROG</li> <li>• Type the User Security Code</li> <li>• Press ENTER</li> <li>• Press 2 for Data</li> <li>• Type Start Time for Monday Period 1</li> <li>• Press ENTER</li> <li>• Type End Time for Monday Period 1</li> <li>• Press ENTER</li> <li>• Repeat if further switching times are required - (Max 3 periods per day)</li> <li>• Press RUN to return to the Normal Run Mode</li> </ul>	<p><b>TIME AND DATE</b></p> <ul style="list-style-type: none"> <li>• Press PROG</li> <li>• Type the User Security Code</li> <li>• Select 3 for System</li> <li>• Select 1 for System Time</li> <li>• Enter the current Time (e.g. 07.00)</li> <li>• Press ENTER</li> <li>• Enter the current date (e.g. 18-06-03)</li> <li>• Press ENTER</li> <li>• Enter the day of the week (e.g. 1=Mon, 7=Sun)</li> <li>• Press RUN twice to return to the Normal RUN mode</li> </ul>
<p><b>OVERRIDING THE HEATMISER</b></p> <ul style="list-style-type: none"> <li>• Press the OVERRIDE key</li> <li>• Enter the User Security Code (if required)</li> <li>• Press ENTER</li> <li>• Press 1 to enter the Override mode</li> <li>• Select either 1 or 2 to override the zone ON(1) or OFF(2)</li> <li>• Now enter the required Override period (e.g. 02 for 2 hours)</li> <li>• Press ENTER mode</li> </ul>	<p><b>PROGRAMMING HOLIDAY PERIODS</b></p> <ul style="list-style-type: none"> <li>• Press PROG</li> <li>• Type the User Security Code</li> <li>• Select 4 for Hols</li> <li>• Enter the holiday start date (e.g. 24-12-03)</li> <li>• Press ENTER</li> <li>• Enter the length of the holiday period (e.g. 10 days)</li> <li>• Repeat for further holidays</li> <li>• Press RUN twice to return to the Normal RUN mode</li> </ul>
<p><b>ALTERING TEMPERATURE SETTINGS</b></p> <ul style="list-style-type: none"> <li>• Press PROG</li> <li>• Type the User Security Code, press enter</li> <li>• Select 1 for Temp</li> <li>• Type the required day temperature (eg. 22°C)</li> <li>• Press ENTER</li> <li>• Select 1 if you require Frost Protection or 2 if you do not</li> <li>• Enter, if required, the Frost setting (e.g. 08°C)</li> <li>• Enter, if required, the summer fan differential Setting. This is the number of °C above the DAY temperature that the summer fan relay will be activated.</li> <li>• Press ENTER</li> <li>• Press RUN to return to the Normal Run Mode</li> </ul>	<p><b>NOTE:</b></p> <ul style="list-style-type: none"> <li>• 24 Hour Clock Notation should be used when programming the Heatmiser.</li> <li>• All Switching times should be actual occupancy times, no warm up period is needed.</li> </ul>

**Harry Taylor South:**

Kitsons Works, Aylesbury Road,  
Bromley, Kent,  
BR2 0QZ, UK

Tel: 020 8464 0915

Email: [southernoffice@harrytaylor.co.uk](mailto:southernoffice@harrytaylor.co.uk)

**Harry Taylor North:**

Guide Bridge Mill, South Street,  
Ashton-under-Lyne, Lancs  
OL7 0UH, UK

Tel: 0161 3084550

Email: [northernoffice@harrytaylor.co.uk](mailto:northernoffice@harrytaylor.co.uk)



[www.harrytaylor.co.uk](http://www.harrytaylor.co.uk)

**The company with the know-how**